


**The Main Event presents . . .**



3495 Laird Road  
Unit 7  
Mississauga, ON, L5L5S5  
T: 905.607.3338  
F: 905.607.2027

W: [www.maineventfun.com](http://www.maineventfun.com)  
E: [info@maineventfun.com](mailto:info@maineventfun.com)

## Cotton Candy (Floss) Instructions



1. Press the **MOTOR** switch to the **ON** position.
2. Fill the spinner head with sugar floss
3. Press the **HEAT** switch to the **ON** position.
4. Turn the **HEAT CONTROL** knob to heat setting **HIGH**.
5. Once the floss starts to flow out of the head, reduce the **HEAT CONTROL** to the green range as indicated on the **METER**.
6. When the amount of floss that's produced starts to slow, add more sugar (usually 5 to 8 servings depending on size). **DO NOT** adjust the **HEAT CONTROL** knob setting.
7. After making the desired amount of floss, press the **HEAT** switch to the **OFF** position and wait 3 to 5 minutes before shutting off the motor.
8. **DO NOT CLEAN MACHINE.** Our Main Event staff will take of the cleaning.

Martin 416-660-8081

Emergency Phone Numbers  
Trevor 416-220-8181

Dwayne 416-937-7884